




HOW TO CONNECT EVO - TO ACM12



THINGS TO NOTE:

- 1) NO Transformer Sharing
- 2) EVERY ACM12 Requires Local Power (1640VAC)
- 3) ACM12's Control 1 Door EACH